

Charger Testing Procedure

- STEP 1 : Plug the charger to the AC power supply
- STEP 2 : Set the digital voltmeter to DCV.
- STEP 3 : Connect digital voltmeter red and black cable as in figure one.
- STEP 4 : A reading at or above 26.7 volts indicates the charger is working
- STEP 5 : A reading under 26.7 volts means you need to replace the charger




Figure 1